

EXPRO National Manual for Projects Management

Volume 11 , Chapter 4

Project Air Surveillance Program Procedure

Document No. EPM-KSH-PR-000005 Rev 003



Project Air Surveillance Program Procedure

Document Submittal History:

Revision:	Date:	Reason For Issue
000	09/10/2017	For Use
001	03/12/2017	For Use
002	19/11/2018	For Use
003	09/08/2021	For Use



Project Air Surveillance Program Procedure

THIS NOTICE MUST ACCOMPANY EVERY COPY OF THIS DOCUMENT

IMPORTANT NOTICE

This document, ("Document") is the exclusive property of Government Expenditure & Projects Efficiency Authority.

This Document should be read in its entirety including the terms of this Important Notice. The government entities may disclose this Document or extracts of this Document to their respective consultants and/or contractors, provided that such disclosure includes this Important Notice.

Any use or reliance on this Document, or extracts thereof, by any party, including government entities and their respective consultants and/or contractors, is at that third party's sole risk and responsibility. Government Expenditure and Projects Efficiency Authority, to the maximum extent permitted by law, disclaim all liability (including for losses or damages of whatsoever nature claimed on whatsoever basis including negligence or otherwise) to any third party howsoever arising with respect to or in connection with the use of this Document including any liability caused by negligent acts or omissions.

This Document and its contents are valid only for the conditions reported in it and as of the date of this Document.



Project Air Surveillance Program Procedure

Table of Contents

1.0	PURPOSE	5
2.0	SCOPE	5
3.0	DEFINITIONS	5
4.0	REFERENCES	6
5.0	RESPONSIBILITIES	6
5.1	Project Manager	6
5.2	Contractors	6
5.3	Health Safety Security & Environment Supervisor (HSSE)	7
6.0	RISK ASSESSMENT	7
7.0	REQUIREMENTS	7
7.1	Air surveillance	7
7.2	Air Monitoring (Direct Methods)	8
7.2.1	Availability and Use	8
7.2.2	Action Levels	8
7.3	Air Monitoring (Indirect Methods)	9
7.4	General Considerations for Sampling	9
7.4.1	Sampling Strategy	9
7.4.2	Sample Type and Location	9
7.4.3	Filter Loading	9
7.4.4	Volume Corrections	10
7.5	Air Sampling for Chemical Contaminants	10
7.5.1	Sampling Duration & Selection of Exposure Standard	10
7.5.2	Gas and Vapor Collection Methodology	10
7.5.3	Particulate Sampling	10
7.5.4	Unknown Contaminants	10
7.6	Air Sampling for Radioactive Contaminants	11
7.6.1	Sampling Strategy	11
7.6.2	Exposure Standards	11
7.6.3	Exposure Control	11
7.6.4	DAC Action Levels	12
7.6.5	Personal Breathing Zone Air Monitoring	12
7.6.6	Perimeter Workplace Monitoring	12
7.7	Recordkeeping	12
7.7.1	Air Surveillance Records	12
7.7.2	HSSE Documentation	12
7.8	Sample Submission	13
8.0	ATTACHMENTS	13
	Attachment 1 - Action Levels for Direct-Reading Measurements in Uncharacterized Atmospheres	14
	Attachment 2 - EPM-KSH-TP-000008 - Personal DAC-Hour Record Template	15
	Attachment 3 - EPM-KSH-TP-000009 - Personal Air Sampling/Monitoring Data Sheet Template	16
	Attachment 4 - EPM-KSH-TP-000010 - Air Sampling/Monitoring Data Sheet Template	17



Project Air Surveillance Program Procedure

1.0 PURPOSE

The purpose of this Procedure is to provide guidance for air surveillance of chemical and radioactive contaminants for determining background, general work area, perimeter, and breathing zone contaminant levels.

2.0 SCOPE

The scope of this procedure applies to all works performed under all Government Construction Contracts executed throughout the Kingdom of Saudi Arabia.

3.0 DEFINITIONS

Definitions	Description
Air Monitoring	Air surveillance with the use of direct-reading instruments capable of providing real-time indication of air contaminant levels.
Air Sampling	The collection of air or airborne contaminants in a suitable container or an appropriate medium for contaminant identification and quantification.
Air Surveillance	The use of direct-reading and air sampling instruments to grossly identify (i.e., gross alpha/beta) and quantify airborne contaminants for personnel protection.
ALARP	As Low As Reasonably Practicable
Annual Limit on Intake (ALI)	The derived limit for radioactive material taken into the body of an adult worker by inhalation or ingestion in a year.
Breathing Zone	The zone of the ambient environment in which a person performs the normal respiratory function (typically, a 12-inch (30.5 cm) hemisphere encompassing the front half of a person's head, neck, and shoulders).
Derived Air Concentration (DAC)	The quantity obtained by dividing the ALI for any given radionuclide by the volume of air respired by an average worker during a working year (in the USA, Appendix A of 10 CFR 835 contains a table of DAC values).
Gas Chromatography/Mass Spectroscopy (GC/MS)	An analytical technique that combines a gas chromatograph for compound separation with a mass spectroscope for compound identification.
HSSE	Health, Safety, Security and Environment
NIOSH	National Institute for Occupational Safety and Health.
Permissible Exposure Limit (PEL)	In the USA, regulatory exposure limits published by the Occupational Safety and Health Administration (OSHA). These limits represent legal standards enforceable by federal administrative courts. In other countries, applicable laws will apply. In the absence of such regulations, the OSHA PELs will be the standard.
STARRT	Safety Task Analysis and Risk Reduction Talk
OSHA	Occupational Safety and Health Standards
Threshold Limit Value (TLV)	In the USA, TLVs are voluntary recommended exposure limits published for chemical and physical agents by the American Conference of Governmental Industrial Hygienists. Since these are recommended levels only, they are guidelines for all operations, in all regions and countries.
TLV-Ceiling C	The concentration that should never be exceeded, even instantaneously.



Project Air Surveillance Program Procedure

Definitions	Description						
TLV-Short Term Exposure Limit (STEL)	The concentration to which workers can be exposed for short periods of time (four 15-minute excursions above the PEL are allowed, with 1 hour between excursions) without suffering from irritation, chronic, or irreversible tissue damage, or deleterious narcosis. This measure supplements the TLV time-weighted average (TWA).						
TLV-TWA	The time-weighted average concentration for a normal 8-hour workday and a 40-hour workweek, to which nearly all workers may be repeatedly exposed, day after day, without adverse effect.						
Lapel Air Sample (Personal Air Sample)	The air sampling method for identifying and quantifying personal exposure to respired contaminants. Samples are obtained in the immediate breathing zone of the employee. The sample collection medium is often attached to the lapel. Lapel samples are defined for the purposes of this procedure as low-volume personal samplers and high-volume personal samplers. Typical flow rates are between 0.01 and 0.2 liter per minute (lpm) for low-volume personal samplers and between 2 and 4 lpm for high-volume personal samplers.						
General Area Sampling	The method by which the air of the work area or perimeter of a defined zone is sampled to determine the concentration of contaminants. General area samples are defined for the purposes of this procedure by required sample flow rate. The categories are: <table><tr><th>Sample Type</th><th>Sample Flow Rate (lpm)</th></tr><tr><td>1. Low-volume area</td><td>< 10</td></tr><tr><td>2. Medium-volume area</td><td>10 - 100</td></tr></table>	Sample Type	Sample Flow Rate (lpm)	1. Low-volume area	< 10	2. Medium-volume area	10 - 100
Sample Type	Sample Flow Rate (lpm)						
1. Low-volume area	< 10						
2. Medium-volume area	10 - 100						

4.0 REFERENCES

- OSHA 1910.119 Hazardous Materials
- HSE, EH40/2005 Workplace exposure limits
- EPM-KSH-PR-000003 Project Occupational Health Records Maintenance System
- EPM-KSS-PR-000007 Project Confined Space Entry Procedure

5.0 RESPONSIBILITIES

5.1 Project Manager

The Project Manager is responsible for ensuring the resources and arrangements are available for the implementation and management of this procedure.

5.2 Contractors

The contractor has the main responsibility for oversight for air quality management for the Project which include duties such as:

- Inspection of sub-contractor areas for compliance with visible emission compliance. (i.e. black smoke, excessive idling).
- Verifying that sub-contractor equipment operators are authorized to operate the intended equipment.
- Maintain fuel storage vessels in a closed position unless loading or unloading.
- Inspection of sub-contractor areas for compliance with fuel storage requirements.



Project Air Surveillance Program Procedure

5.3 Health Safety Security & Environment Supervisor (HSSE)

In conjunction with the Construction Site Manager or Field Manager (CSM/FM), the HSSE Supervisor is responsible for implementing and administering this procedure. The HSSE Supervisor will:

- Select, maintain, calibrate, and use instrumentation necessary for monitoring/sampling of airborne contaminants;
- Maintain monitoring records on site;
- Evaluate air surveillance data to determine exposure, exposure potential, and necessary controls.

6.0 RISK ASSESSMENT

Airborne contaminants can present a significant threat to worker health and safety. Thus, identification and quantification of these contaminants through air monitoring is an essential component of a health and safety program where people could be exposed to airborne contaminants.

Exposure measurement is required:

- When assessing hazardous substances, to help in selecting the right controls.
- Where there is a serious risk to health from inhalation of the substance.
- To check that exposure limits are not exceeded.
- To check that exposure controls work well enough, or if improvements are required.
- To check that new controls work well enough.
- To help choose the right level of respiratory protection.
- After process or production changes that mean exposure may have changed.
- To show any need for health surveillance.
- When an issue has been identified that requires monitoring.

It is imperative that prior to beginning any work activity, a STARRT briefing occurs to discuss the contents of the WMS/JHA which includes mitigations for any other hazards noted by the crew at the jobsite. The discussion shall also include job steps, expected hazards associated with the activity, and the mitigation and protection methods that shall be implemented to prevent incidents.

If circumstances change by way of the environment, other work crews are in the area, additional hazards are now present, change of methodology of the task etc..... another STARRT briefing shall occur.

The Hierarchy of control shall be used to reduce the likelihood of an incident occurring.

- **Elimination** (Remove the Hazard)
- **Substitution/Isolation** (Replacing material, process or hazard with a lower risk one/ separate people from the hazard (such as suitable guarding, distance, etc.)
- **Engineering Controls** (Redesign or replacement of plant and equipment)
- **Administration Controls** (Procedures, training, signage)
- **PERSONAL PROTECTIVE EQUIPMENT**

No work is to commence until the above has been implemented and signed by the relevant Supervisor in charge.

7.0 REQUIREMENTS

7.1 Air surveillance

Consists of air monitoring and air sampling. The objectives of air sampling are to determine:

- The type of radioactive (ionizing & non-ionizing) or chemical compounds present.
- The hazards associated with these compounds.
- The quantity of airborne contaminants.
- Oxygen deficient/excessive atmospheres.



Project Air Surveillance Program Procedure

- Explosive atmospheres, etc.

Air surveillance will be carried out with the use of air monitoring instruments to screen for the presence of airborne contaminants. If unknown contaminants are detected, the action levels outlined in Attachment 1 are to be used. As unknown contaminants are identified through air sampling and laboratory analysis, comparisons of applicable exposure standards and air sampling results will be made to determine suitable exposure control measures.

To assess the impact of work operations on personnel and the environment, measurements will be taken in various locations, including personal (breathing zone) area, work areas, downwind perimeter areas, and upwind background areas. Data obtained from these locations will be used to establish worker protection levels and to assess the effectiveness of engineering controls and the impact of work operations upon the environment.

Biased air surveillance techniques will be employed based on worst-case exposure situations. Where appropriate, full-shift, time-weighted average measurements will be compared with applicable exposure standards such as PEL, TLV, or DAC.

7.2 Air Monitoring (Direct Methods)

Some of these instruments may be used in the total organic vapor or gas chromatographic mode. Radiological continuous air monitors (RCAMs) will be used to give early warning of airborne radioactivity. RCAM alarm levels will be set at levels that are less than the most restrictive DAC that may be encountered at the project/facility.

The primary sources of information concerning specific instruments are the manufacturers' reference documents. These should be consulted for operation, maintenance, and calibration specifications.

7.2.1 Availability and Use

Project work facilities will have direct-reading instrumentation available during drilling or other major intrusive activities. Trained personnel will use this instrumentation to conduct air monitoring for work efforts.

For work efforts in areas suspected of containing radioactive or chemical contaminants, the air will be monitored as specified by the HSSE Representative.

Minimum air surveillance measurements for intrusive work activities (i.e., drilling, excavation into known and/or suspected contaminated areas) include monitoring for oxygen, combustible gas, total volatile organic compounds, and airborne radioactive material.

Air sampling for specific potentially toxic compounds may also be conducted to aid in further assessing the adequacy of project-work-element-specified personal protective equipment (PPE) levels. EPM-KSS-PR-000007 Project Confined Space Entry Procedure monitoring will comply.

Direct-reading instruments will be used to screen for commonly encountered organic or inorganic gases such as methane and hydrogen sulfide. Direct-reading aerosol monitors may also be used to quantify total particulate levels resulting from intrusive activities.

A trained, qualified HSSE Representative, with consultation and concurrence provided by the project environmental, safety, and health supervisor, will implement air surveillance and sampling procedures.

7.2.2 Action Levels

The guidelines presented in Attachment 1 illustrate action levels for vapor, combustible gas, oxygen, particulate measurements, and airborne radioactivity of unidentified types. These levels should be used in conjunction with all other available information such as historical radiological or chemical use and disposal information.

Data from vapor, gas, particulate, or radiological measurements, as determined by direct-reading instruments, will be used as a supplement to other information and not as the single selection criterion.



Project Air Surveillance Program Procedure

Many potentially toxic inorganic, semi-volatile, or particulate compounds do not elicit a response from commonly used direct-reading instruments.

7.3 Air Monitoring (Indirect Methods)

Contaminant identification and accurate quantification usually require sample collection followed by laboratory analysis. Air sampling pumps with filter, solid sorbent, or other collection devices are commonly used. Indirect air samples will be collected and analyzed using nationally recognized protocols such as National Institute for Occupational Safety and Health (NIOSH) reference procedures and methods.

Air sampling for radioactive materials is like conventional particulate contaminant sampling methods. However, important differences do exist, including the concept of radioactive decay, which is an important consideration when sampling for short-lived isotopes such as radon progeny.

General recommendations for air sampling of chemical contaminants are included in Section 7.5.

General recommendations for air sampling of radioactive contaminants are included in Section 7.6.

7.4 General Considerations for Sampling

Practical considerations for radiological and chemical contaminant sampling include sampling strategy, sample type and location, filter loading, and volume corrections.

7.4.1 Sampling Strategy

The HSSE Representative will develop specific sampling strategies for hazardous work permits, as needed. Air samples will be obtained and analyzed as indicated by direct-reading results.

Direct-monitoring results above the action limit, requiring upgrade to a higher level of protection, will mandate air sampling for organic, inorganic, and/or radioactive contaminants. In addition, random screening samples will be obtained during major work operations where contaminants are disturbed with mechanized equipment (e.g., drilling, split-spoon sampling) to determine the reliability of the direct-reading results.

In general, more samples are obtained during early phases of major task work to assist in the proper selection or verification of proper selection of PPE, and the concept of biased sampling is used. For example, when personal samples are collected, employees with the most potential for exposure are selected to wear the sampling apparatus.

The biased sampling philosophy represents a conservative approach. PPE will be selected based on data indicating the highest probable exposure, thus ensuring adequate protection for all workers.

7.4.2 Sample Type and Location

General Area Samples: General area samples will be obtained in the work area and at controlled access area perimeters to estimate potential worker exposure and environmental exposures, respectively. Work area samples will be obtained near generation sources to estimate the most severe potential exposure. Perimeter samples will be obtained in upwind and downwind locations to determine background and work activity impact upon uncontrolled areas.

Personal Samples: Personal breathing zone (lapel) air samples will be obtained if airborne concentrations exceed, or are expected to exceed, 10 percent of the applicable airborne limit (DAC, TLV, etc.). The need for personal samples is generally based on the results of work area samples.

7.4.3 Filter Loading

Filter loading is an important sampling consideration from a chemical and radiological standpoint. Overloading of the filter may cause underestimation of exposure due to the loss of material during filter weighing or sample



Project Air Surveillance Program Procedure

cassette unloading. Self-absorption of alpha particles is a source of analytical bias with overloaded filters. Filter loading must be kept as low as possible to minimize alpha self-absorption. Projected sample times will be calculated and actual sampling duration adjusted to prevent filter loading.

7.4.4 Volume Corrections

Volume corrections may be necessary if sample pumps use variable flow meters (rotameters) for flow rate indication. The correction is not made for non-rotameter sampling pumps. The following formula is employed to calculate the average sample flow rate occurring during the total sample period:

$$\bar{Q} = \text{Average flowrate (l / min)} = \frac{Q(\text{install}) + Q(\text{final})}{2}$$

The average sample flow rate (Q) is then multiplied by the total sample duration to calculate the total sample volume.

7.5 Air Sampling for Chemical Contaminants

Sampling for chemical contaminants may involve a variety of methods, including the use of impingers, impactors, cyclones, filters, and solid sorbents (carbon, silica gel, Tenax^R, etc.).

The selection of collection devices will depend on the physical and chemical properties of the contaminants. Sampling protocols developed by NIOSH (or international equivalent) will be used for chemical sampling efforts. The analytical support subcontractor must be contacted for specialized sampling and analytical methods for which standard protocols do not exist.

7.5.1 Sampling Duration & Selection of Exposure Standard

Chemical exposure standards, such as the TLVs, define sampling periods in relation to specific physiological responses. The HSSE Representative will select appropriate sampling times based on the nature of the expected contaminant. For example, with an acutely toxic or irritating material such as cadmium oxide, the ceiling TLV is the most important parameter. For cumulatively toxic compounds such as inorganic lead or mercury, an estimate of daily average exposure is usually best. The corresponding standard would be the TLV-TWA. Sample times are also based on the nature of the work operation and exposure (continuous, intermittent, etc.).

7.5.2 Gas and Vapor Collection Methodology

Adsorption tubes (carbon, silica gel, Tenax^R) are commonly used for gas and vapor collection. Other methods, such as sampling flasks or bags, may also be employed if, in the judgment of the HSSE Representative, they are called for.

Adsorption tubes typically use a minimum of two sections. Backup sections of the adsorption tubes are analyzed separately. Sampling results are suspected of underestimating exposure if the second adsorption stage contains more than 25 percent of the mass collected in the front section. The HSSE Representative should note on the sampling sheet that contaminant breakthrough with consequent underestimation of exposure occurred. Future samples should adjust sample volume to prevent breakthrough.

7.5.3 Particulate Sampling

Particulate sampling is commonly done for total mass or for the fraction of mass considered to be respirable for chemical contaminants. Other sampling devices, such as impingers, impactors, electrostatic precipitators, etc., may be employed if, in the judgment of the HSSE Representative, they are called for. Filters used for gravimetric analysis must be desiccated in an evacuated desiccation chamber and weighed before and after use.

7.5.4 Unknown Contaminants



Project Air Surveillance Program Procedure

Atmospheres that contain unknown organic or inorganic contaminants, as detected by direct-reading instruments, will be sampled with solid sorbents that collect a wide variety of substances. Tenax[®], carbon, or other sample sorbents as recommended by the analytical subcontractor will be used to sample unknown atmospheres.

Analysis to determine the nature of unknowns will be carried out with GC/MS systems to separate and identify unknown compounds. Chemicals identified in this manner will then be analyzed with internationally recognized methods (such as those outlined in the NIOSH Manual of Analytical Methods).

7.6 Air Sampling for Radioactive Contaminants

Project radiation protection programs, plans, and procedures will be prepared in accordance with the guidance provided by the regulators having primacy.

7.6.1 Sampling Strategy

Air sampling for radioactive contaminants will be task-specific and based on the potential presence of radioactive materials. Priority will be given to situations in which aerosols can be generated (drilling, excavation, sampling of dry soils, decontamination activities, etc.).

When work operations necessitate the use of respiratory protection, breathing zone (lapel) air sampling will be conducted. Filters for sampling should prevent subsurface deposition of particulates. Filters suitable for this purpose include SM Millipore[®] and Nucleopore[®] polycarbonate membrane.

Air sample filters will be analyzed for alpha and/or beta-gamma, with emphasis on the comparison to applicable DACs of radionuclides known to be in the workplace. If contaminants have not been identified in a work area, conservative DACs will be used to determine action levels.

7.6.2 Exposure Standards

Exposure standards are used to control internal exposures to radioactive materials. Under extreme conditions, external exposure to radionuclides may be the limiting condition. Under such circumstances, limitations on occupancy may be governed by considering both external and internal exposure limits.

An airborne radioactivity area warning sign will be posted if airborne radioactivity exceeds or has the potential to exceed 10 percent of the DAC. Personal air samples are required for everyone who enters known or potential airborne radioactivity areas.

7.6.3 Exposure Control

Exposure to airborne radioactive materials is controlled by assessing derived air concentration - hours (DAC-HRs) exposures.

Records of individual exposure (in DAC-HRs) will be maintained (Attachment 2). Records are required if personnel exposure is expected to exceed 4 DAC-HRs in a single week. DAC-HRs are calculated in the following manner:

For single nuclides:

$$DAC - HRS = \frac{(fractionDAC) \times (hours of exposure)}{(protection factor)}$$

For multiple nuclides:

$$Fraction DAC = \frac{Concentration A}{DAC A} + \frac{Concentration B}{DAC B}$$

Respiratory protection is required for entry into areas with airborne radioactivity greater than the DAC.



Project Air Surveillance Program Procedure

7.6.4 DAC Action Levels

Personnel entry into airborne radiation areas with exposure potentials that exceed 10 DAC-HRs in any consecutive 7-day period is prohibited without prior approval of the HSSE Representative.

Personnel entry into airborne radiation areas with exposure potentials that exceed 20 DAC-HRs in any consecutive 7-day period is prohibited without prior approval of the HSSE Representative.

Personnel who exceed 5 DAC-HRs in a calendar quarter must participate in the bioassay program.

7.6.5 Personal Breathing Zone Air Monitoring

Personal breathing zone (lapel) samples are required for workers who enter areas that exceed 10 percent of the DAC as measured by area sampling techniques. The biased sampling protocol outlined in Section 6.1 will be used to select workers for personal samples. For a form that contains a sample that is used to record relevant sampling information. (see Attachment 3).

7.6.6 Perimeter Workplace Monitoring

Area samples will be collected at the boundary of radiologically controlled access areas to document the effectiveness of site controls that should keep exposure to offsite individual(s) as low as reasonably practical (ALARP).

Perimeter monitors or samplers will be placed in predominately downwind areas around the work facility and in at least one upwind area to measure contamination migration away from the facility in relation to background. These measurements will allow the HSSE Representative to evaluate the integrity of the clean areas.

7.7 Recordkeeping

Maintenance of appropriate records is essential for a complete air surveillance program. The following are the minimum requirements:

7.7.1 Air Surveillance Records

Air surveillance for chemical and particulate contaminants will be recorded. Records will be forwarded to the project document control center, and then forwarded to the project HSSE Supervisor, who will forward the pertinent records to the Occupational Health Records Maintenance System.

Completed monitoring data sheets; copies of available bioassay reports; and correspondence relating to exposure evaluation, summaries, and reporting will be retained in the project site HSSE files.

At a minimum, the following air monitoring data will be completed:

- Copy of the air monitoring data sheets, which include instrument calibration. (Attachments 3 & 4)
- Chain-of-custody record.
- Copy of chemical laboratory work order forms.
- Copy of analytical results.

7.7.2 HSSE Documentation

The HSSE Representative will document the following information:

- Date of sampling.
- Operation monitored.
- Location of sampling.
- Meteorology data.
- Time of monitoring.



Project Air Surveillance Program Procedure

- Monitoring/sampling equipment operated.
- Source(s) of contamination.
- Suspected contaminants.
- Exact time the monitoring/sampling equipment was operated.
- Who performed the equipment calibration.
- When and how the equipment was calibrated.
- Date of equipment calibration.
- Complicating or mitigating factors.

The HSSE Representative will calculate analytical results immediately upon receipt of data. To eliminate delays, laboratory results will be sent to the HSSE Representative so calculations can be completed for implementation of proper controls in a timely manner.

7.8 Sample Submission

Where applicable, air sampling collection media requiring laboratory analyses will be analyzed by a laboratory accredited by an appropriate agency (such as the American Industrial Hygiene Association) or one successfully participating in the NIOSH Proficiency in Analytical Testing Program. Samples are to be properly packaged and shipped.

8.0 ATTACHMENTS

1. Action Levels for Direct-Reading Measurements in Uncharacterized Atmospheres
2. EPM-KSH-TP-000008 - Personal DAC-Hour Record
3. EPM-KSH-TP-000009 - Personal Air Sampling/Monitoring Data Sheet
4. EPM-KSH-TP-000010 - Air Sampling/Monitoring Data Sheet



Project Air Surveillance Program Procedure

Attachment 1 - Action Levels for Direct-Reading Measurements in Uncharacterized Atmospheres

Contaminant Category	Action Level ^a	Action ^b
Organic gases/vapors	Background to 5 ppm above background	Monitor contaminant level in or near the breathing zone of workers. Use modified C or Level C protection.
	> 5 ppm to 500 ppm	Upgrade protection to Level B and obtain further information. Analyze sorbent samples by GC/MS.
	> 500 ppm to 1000 ppm	Upgrade protection to Level A and obtain further information. Analyze sorbent samples by GC/MS.
	> 1000 ppm	Stop work activities.
Combustible gas ^c	> 10 % LEL	Requires continuous (as practical) monitoring.
	< 20 % LEL	Limit activities in the area to those that do not generate sparks. Use nonsparking tools and gear. Investigate the source of the combustible gas.
	20 % LEL	Limit all activities in area. Stop work activities.
Oxygen	< 19.5 %	Monitor while wearing SCBA.
	19.5 % to 25 %	Continue measurements with respiratory protection equipment based on other factors such as the presence of toxic air contaminants.
	> 25 %	Fire hazard potential exists. Stop work activities.
Particulate (respirable dust)	2 mg/m ³	Use modified C or Level C protection. Air purifying respirator should be equipped with high-efficiency/organic vapor/acid gas combination cartridges. Basic dust control techniques will be used for all intrusive activities.
	> 2 mg/m ³ to 10 mg/m ³	Upgrade to Level B protection. Collect air sample information.
	> 10 mg/m ³ to 20 mg/m ³	Upgrade to Level A protection. Collect air sample information.
	> 20 mg/m ³	Stop work activities.
Particulate (radioactive materials using a respirable dust monitor)	0.1 DAC	Monitor contaminant level in occupied work area.
	> 0.1 DAC to 1 DAC	Post area as an airborne radioactive area. Use HWP to specify respiratory protection requirements. Collect samples of contaminant in occupied work area and in breathing zone of workers.
	> 1 DAC	Post area as an airborne radioactive area. Use HWP to specify respiratory protection requirements. Collect samples to monitor contaminant in occupied work area with continuous air monitors and in breathing zone of workers. Track cumulative exposure and maintain exposures ALARP.

^a~~Readings~~ in the immediate vicinity of the borehole or other intrusive activity.

^b~~Refer~~ to CP-306, Personal Protective Equipment, for guidance on personal protective equipment.

^c~~Low~~ oxygen concentrations may affect the validity of combustible gas measurements.



Project Air Surveillance Program Procedure

Attachment 2 - EPM-KSH-TP-000008 - Personal DAC-Hour Record Template

Name:			Company:		Emp. No.:	
Day of Month	Month		Month		Month	
	Daily Total	7-Day Total	Daily Total	7-Day Total	Daily Total	7-Day Total
1						
2						
3						
4						
5						
6						
7						
8						
9						
10						
11						
12						
13						
14						
15						
16						
17						
18						
19						
20						
21						
22						
23						
24						
25						
26						
27						
28						
29						
30						
31						
Total						



Project Air Surveillance Program Procedure

Attachment 3 - EPM-KSH-TP-000009 - Personal Air Sampling/Monitoring Data Sheet Template

ESHR		Survey No.		Date	
Weather Conditions		HWP No.			
		Level of PPE			
Worker Activities					
Monitored Worker - Name		SSN (or ID)	Company	Employee #	
Other Workers in Group					
Worker Name		SSN (or ID)	Company	Employee #	
Sample Type: ☐ Personal ☐ Area		Sample Media: ☐ Mixed Cellulose Ester ☐ Charcoal Tube ☐ Glass Fiber ☐ Other (describe)			
Pump Manufacturer			Model	Serial	
Calibration Data	Date & Time	Calibrator	Measurement 1 (liters/min)	Measurement 2 (liters/min)	Measurement 3 (liters/min)
Pre-Cal					
Post-Cal					
Average Pre/Post Flow Rate: Liters/min					
Pump Use Time Started		Time Stopped		Comments	
Total Sampling Time:			Sample Volume:		
ESHR's Signature				Date	

Project Air Surveillance Program Procedure

Attachment 4 - EPM-KSH-TP-000010 - Air Sampling/Monitoring Data Sheet Template

[illegible]